




**RAPID SAUSAGE FILLER HURAKAN HKN-ISA15, ISA26, ISA35**

| Ref. | Part name                           |
|------|-------------------------------------|
| 1    | Motor                               |
| 2    | Flange                              |
| 3    | Motor Connector                     |
| 4    | Oil seal                            |
| 5    | Oil box cap                         |
| 6    | Oil box plate                       |
| 7    | Oil pump connector                  |
| 8    | Oil pump                            |
| 9    | Filter                              |
| 10   | Oil box                             |
| 11   | Screws                              |
| 12   | External Gasket for oil tank piston |
| 13   | Oil tank piston                     |
| 14   | Internal Gasket for oil tank piston |
| 15   | Piston Rod                          |
| 16   | External gasket for Guide sleeve    |
| 17   | Guide sleeve                        |
| 18   | Internal gasket for guide sleeve    |
| 19   | Dust cover                          |
| 20   | Internal gasket for dust cover      |
| 21   | Piston Support frame                |
| 22   | Plunger/piston                      |
| 23   | Gasket for piston                   |
| 24   | Top cover                           |
| 25   | Spring                              |
| 26   | Oil tank                            |
| 27   | Oil tank connector                  |
| 28   | Gasket for oil tank connector       |
| 29   | Magnetic valve                      |
| 30   | Overflow valve                      |
| 31   | Circuit block                       |
| 32   | Support frame                       |
| 33   | Side plate                          |
| 34   | Support frame                       |
| 35   | Fuse                                |
| 36   | Transformer                         |
| 37   | Foot pedal                          |
| 38   | Stuffing nozzle                     |
| 39   | Gasket for nozzle                   |
| 40   | Trefoil nut                         |
| 41   | cylinder Locking Screw              |
| 42   | Gasket for cylinder                 |
| 43   | Cylinder                            |
| 44   | Bar                                 |
| 45   | Bar                                 |
| 46   | Plate                               |
| 47   | Support plate                       |
| 48   | Relay                               |
| 49   | Timer                               |
| 50   | Switch                              |
| 51   | Emergency switch                    |
| 52   | Overload protection                 |
| 53   | Main body                           |
| 54   | Throttle valve                      |
| 55   | Castors                             |
| 56   | Back cover                          |
| 57   | Universal castors                   |