




**TOASTER HURAKAN HKN-TPT4**

Ref.	Part name
1	Body
2	Side cover
3	Power cord
4	Crumb tray
5	Plug
6	Toast level
7	Heating element
8	Vover grid
9	Feet
10	Level hole cover
11	Spring
12	Level handle
13	Timer
14	Timer knob
15	Power light
16	Connector
17	Bush
18	Selection switch