



**ELECTRIC FRYER HURAKAN HKN-FT4N**

Ref.	Part name
1	Power line
2	Cover of electric box
3	Ceramic connector
4	Safety switch
5	Electric box
6	Hanging for basket
7	Protect board for heating element
8	EGO 190°C Thermostat
9	Heating tube
10	Oil pot
11	Frame
12	Handle of frame
13	Rubber feet
14	Layer of frying basket
15	Frying basket+handle
16	Cover of oil pot
17	Handle of cover
18	Switch knob
19	Indicate light
20	Main switch
21	Temperature limiter