


EXPLODED VIEW FOR POTATO PEELER HKN-PPF15



PARTS FOR HLP-15		
Code	Part Name	
15-1	Cover of switch	
15-2	Timer	
15-3	Gasket	
15-4	Spindle	
15-5	Scam	
15-6	Blocker	
15-7	Microswitch	
15-8	Handle	
15-9	Cover	
15-10	Box of switch	
15-11	Out switch	
15-12	Stop switch	
15-13	Start switch	
15-14	Knob of timer	
15-15	Feeding tap	
15-16	Screw	
15-17	Hopper	
15-18	Pusher	
15-19	Cap	
15-20	Sand cover	
15-21	Pan	
15-22	Discharge door	
15-23	Handle of discharge door	
15-24	Blocker	
15-25	Lever arm	
15-26	Turner	
15-27	Sealing ring	
15-28	Spindle	
15-29	Bearing	
15-30	Isolation tube	
15-31	Sealing ring	
15-32	Belt wheel	
15-33	Electric board	
15-34	Belt	
15-35	Motor	
15-36	Seat for motor	
15-37	Fixing board	
15-38	Adjusting feet	
15-39	Supporting	
15-40	Feet	
15-41	Tap	
15-42	Water pan	
15-43	Screw	
15-44	Stand	
15-45	Bottom	
15-46	Wire and plug	
15-47	Cord	
15-48	Maintenance door	
15-49	Side door	
15-50	Seat	
15-51	Safety switch	
15-52	Pan block hinge	
15-53	Rubber gasket	
15-54	Driver seat	
15-55	Pillar	

PARTS FOR HLP-20		
Code	Part Name	
15-1	Cover of switch	
20-2	Timer	
20-3	Gasket	
20-4	Spindle	
20-5	Scam	
20-6	Blocker	
20-7	Microswitch	
20-8	Handle	
20-9	Cover	
20-10	Box of switch	
20-11	Out switch	
20-12	Stop switch	
20-13	Start switch	
20-14	Knob of timer	
20-15	Feeding tap	
20-16	Screw	
20-17	Hopper	
20-18	Pusher	
20-19	Cap	
20-20	Sand cover	
20-21	Pan	
20-22	Discharge door	
20-23	Handle of discharge door	
20-24	Blocker	
20-25	Lever arm	
20-26	Turner	
20-27	Sealing ring	
20-28	Spindle	
20-29	Bearing	
20-30	Isolation tube	
20-31	Sealing ring	
20-32	Belt wheel	
20-33	Electric board	
20-34	Belt	
20-35	Motor	
20-36	Seat for motor	
20-37	Fixing board	
20-38	Adjusting feet	
20-39	Supporting	
20-40	Feet	
20-41	Tap	
20-42	Water pan	
20-43	Screw	
20-44	Stand	
20-45	Bottom	
20-46	Wire and plug	
20-47	Cord	
20-48	Maintenance door	
20-49	Side door	
20-50	Seat	
20-51	Safety switch	
20-52	Pan block hinge	
20-53	Rubber gasket	
20-54	Driver seat	
20-55	Pillar	