

# HKN-M6/HKN-MC6

1. Base
2. M5 screw
3. Spring
4. Powder pusher
5. M6 setscrew for powder pusher
6. Blade holder
7. Scale adjuster
8. Scale adjustment screw
9. Funnel
10. Funnel cap
11. Fuse holder
12. Power switch
13. Motor
14. Silicon rubber case
15. Baseplate
16. Backup fuse
17. M3 baseplate screw
18. Foot pad
19. Coffee powder container (for LD-018 only)
20. Cap of coffee powder container (for LD-018 only)
21. M4 screw
22. Fluted disks
23. Micro-switch holder
24. Micro-switch
25. Handle holder (for LD-019 only)

